

PCX-200









Portable industrial scale and separate display

Its extra-flat platform and separate display make it ideal for use on a wall or benchtop.

- · Industrial scale with stainless steel plate.
- · Separate display with extendable cable.
- · Highly resistant internal structure.
- · Low height weighing platform, only 70 mm.
- · Tare function for containers or boxes.
- · Illuminated display for easy reading.
- · Automatic switch off function when using internal batteries.
- · Power supply: 220 V mains connection or internal batteries.
- · Capacity 200 kg and resolution 50 g.
- · Operating time with internal batteries, up to 50 hours.

The **Accurex PCX-200** scale is made of highly resistant materials. It is a product for industrial use, specially designed for weighing heavy objects.





n a

The display has 1.5 m of extendable cable and can be placed on a bench or mounted on the wall (support bracket included). Weighing response is extremely fast, in less than 2 seconds, and shows a stable, accurate weight.

It is powered by a 220 V mains supply or by its internal battery (included).

Technical features

Model	PCX-200
Reference	71962
Capacity	200 kg
Resolution	50 g
Weighing units	kg, lb, oz
Power	220 V, 50 Hz mains or 4 x 1.5 V AA batteries
Working temperature	0° / +40°C
Structure	ABS and stainless steel
Weighing platform dimensions (mm)	310 x 390
Net weight (kg)	3.3
Packaging dim. (mm)	430 x 480 x 45
Total weight with packaging (kg)	3.9



Operational functions

Zero adjustment function. Possibility of zeroing the device to zero by pressing a key.

Tare function. The container or box weight can be deducted by pressing the tare key.

Serial calibration. The device is supplied calibrated and adjusted by our Barcelona calibration laboratory (audited annually by the European notified body NMI).

External dimensions (mm)

